
A	DI	ור	7 7	T		W	٨
\boldsymbol{H}	ГΙ	- 1	Γ	NI	ועו	Λ	$\overline{}$

Exploded and Overall Views of the Example Servovalve Input Linkage Components

PARKER HANNIFIN CORPORATION COMPONENT MAINTENANCE MANUAL PART NO. 282700



Elevator Power Control Actuator, Part No. 282700 IPL Figure 1 (Sheet 2 of 3)





Figure 2 – Example of Overtravel Crank from Servovalve Input Linkage





Figure 3 – Example of Overtravel Cam from Servovalve Input Linkage





Figure 4 – Example of Overtravel Cam from Servovalve Input Linkage



Figure 5 – Example of Installation Orientation for Overtravel Crank and Overtravel Cam from Servovalve Input Linkage